

# KLOPFENSTEIN EASEL CART (EC100) ***SAFETY SHEET***

**\*WILL HOLD 8-10 EASELS\***

**Use caution when operating this product, to prevent injury to yourself or others.**

**Sudden changes in direction or traveling across uneven surfaces, may cause easels to shift**



## **INCLUDED:**

- (4) clevis pins
- (4) 3" single lock casters
  - (8) 3/4" bolts

## **ASSEMBLY:**

- (4) Casters to be installed with 1/2" bolts (16) and lock washers (16) using 9/16" wrench or socket to tighten.
- (8) 3/4" Bolts to be tightened on Cart Upright Tubes using 9/16" wrench or socket.
- (4) Clevis Pins with wire gates used to install handle on cart.

Any questions or concerns on the product please contact us at (419) 884-2900

